

# **ICC-ES** Report

ICC-ES | (800) 423-6587 | (562) 699-0543 | www.icc-es.org

# Most Widely Accepted and Trusted

# **ESR-1361**

Issued 08/2016 This report is subject to renewal 08/2017.

# DIVISION: 06 00 00—WOOD, PLASTICS AND COMPOSITES SECTION: 06 50 00—STRUCTURAL PLASTICS

**REPORT HOLDER:** 

# HB&G BUILDING PRODUCTS, INC.

1015 BRUNDIDGE BOULEVARD POST OFFICE BOX 589 TROY, ALABAMA 36081

# **EVALUATION SUBJECT:**

STRUCTURAL FIBERGLASS FIRE RATED COLUMNS (HB&G PermaCast<sup>®</sup> Fire Rated, Dixie Pacific DuraCast<sup>™</sup> Fire Rated, Crown Column<sup>™</sup> Fire Rated, SpunCast Structural Fiberglass Column<sup>™</sup> Fire Rated and Hartmann Sanders<sup>®</sup> Fire Rated)

STRUCTURAL FIBERGLASS COLUMNS (HB&G PermaCast®, Dixie Pacific DuraCast™, Crown Column™, SpunCast Structural Fiberglass Column™ and Hartmann Sanders®)



Look for the trusted marks of Conformity!

*"2014 Recipient of Prestigious Western States Seismic Policy Council (WSSPC) Award in Excellence"* 

ICC-ES Evaluation Reports are not to be construed as representing aesthetics or any other attributes not specifically addressed, nor are they to be construed as an endorsement of the subject of the report or a recommendation for its use. There is no warranty by ICC Evaluation Service, LLC, express or implied, as to any finding or other matter in this report, or as to any product covered by the report.

Copyright <sup>©</sup> 2017 ICC Evaluation Service, LLC. All rights reserved.





A Subsidiary of CODE COU







# **ICC-ES Evaluation Report**

# **ESR-1361**

Issued August 2016 Revised February 2017 This report is subject to renewal August 2017.

www.icc-es.org | (800) 423-6587 | (562) 699-0543

DIVISION: 06 00 00—WOOD, PLASTICS AND COMPOSITES Section: 06 50 00—Structural Plastics

#### **REPORT HOLDER:**

HB&G BUILDING PRODUCTS, INC. 1015 BRUNDIDGE BOULEVARD POST OFFICE BOX 589 TROY, ALABAMA 36081 (334) 566-5000 800-264-4HBG www.hbgbuildingproducts.com marketing@hbgcompanies.com

### **EVALUATION SUBJECT:**

# STRUCTURAL FIBERGLASS FIRE RATED COLUMNS

(HB&G PermaCast<sup>®</sup> Fire Rated, Dixie Pacific DuraCast<sup>™</sup> Fire Rated, Crown Column<sup>™</sup> Fire Rated, SpunCast Structural Fiberglass Column<sup>™</sup> Fire Rated and Hartmann Sanders<sup>®</sup> Fire Rated)

#### STRUCTURAL FIBERGLASS COLUMNS

(HB&G PermaCast<sup>®</sup>, Dixie Pacific DuraCast<sup>™</sup>, Crown Column<sup>™</sup>, SpunCast Structural Fiberglass Column<sup>™</sup> and Hartmann Sanders<sup>®</sup>)

# 1.0 EVALUATION SCOPE

# Compliance with the following codes:

- 2015, 2012 and 2009 International Building Code<sup>®</sup> (IBC)
- 2015, 2012 and 2009 International Residential Code<sup>®</sup> (IRC)

# **Properties evaluated:**

- Structural
- Surface Burning Characteristics
- Weather Resistance

# 2.0 USES

Structural Fiberglass Fire Rated Columns are used as interior load-bearing and nonload-bearing (decorative) columns in buildings of Type III, IV and V construction, nonfire-resistance rated and any construction under the IRC. Interior load-bearing columns are used to resist gravity axial loads.

Structural Fiberglass Columns are used as exterior loadbearing and nonload-bearing (decorative) columns on buildings of Type V-B construction under the IBC and any A Subsidiary of the International Code Council®

construction under the IRC. Exterior load-bearing columns are used to resist gravity axial loads.

# 3.0 DESCRIPTION

# 3.1 General:

Structural Fiberglass Fire Rated Columns and Structural Fiberglass Columns are spuncast hollow Fiber-Reinforced Polymer FRP composite columns produced in two formulations, one for interior use and one for exterior use respectively. The columns are produced in both round and square cross sections. The round columns are available in plain and fluted styles. The round columns are tapered toward the top of the column and the wall thickness varies. The round columns are produced in nominal sizes of 8, 10, and 12-inch (203, 254, and 305 mm) diameter. The square columns are produced in a plain style and plain with optional molding. The square columns are not tapered. The square columns are produced in nominal sizes of 6, 8, 10, and 12-inch (152, 203, 254, and 305 mm) dimensions. Structural load bearing columns are limited to the sizes and lengths shown in Table 1. Decorative nonload-bearing columns may be any size and length produced and are also supplied as factory split columns. Column caps and bases are available in various styles. Dimensions of decorative columns are shown in the manufacturer's literature.

Structural Fiberglass Columns were subjected to accelerated weathering, salt spray exposure, freeze-thaw, and resistance to deicing chemicals.

# 3.2 Surface Burning Characteristics:

**3.2.1** Structural Fiberglass Fire Rated Columns at a minimum  $^{1}/_{4}$  inch (6.35 mm) thickness have an flame spread index (FSI) of 75 or less and an smoke-development index (SDI) of 450 or less, Class B Interior Finish classification, when tested in accordance with ASTM E84.

**3.2.2** Structural Fiberglass Columns have a flame spread index (FSI) of less than 200, qualifying for exterior use, when tested in accordance with ASTM E84.

# 4.0 DESIGN AND INSTALLATION

# 4.1 General:

Structural Fiberglass Fire Rated Columns and Structural Fiberglass Columns are installed in accordance with the manufacturer's published installation instructions and this report.

The manufacturer's published installation instructions and this report must be strictly adhered to and a copy of

ICC-ES Evaluation Reports are not to be construed as representing aesthetics or any other attributes not specifically addressed, nor are they to be construed as an endorsement of the subject of the report or a recommendation for its use. There is no warranty by ICC Evaluation Service, LLC, express or implied, as to any finding or other matter in this report, or as to any product covered by the report.



these instructions must be available at all times on the job site during installation.

The instructions within this report govern if there are any conflicts between the manufacturer's instructions and this report.

#### 4.2 Design:

Structural Fiberglass Columns used as load-bearing columns are limited to the sizes and lengths shown in Table 1. The columns are designed to resist gravity loads.

Design loads shall be determined using Chapter 16 of the IBC and must not exceed the loads shown in Table 1. The design values are applicable for temperatures not exceeding  $125^{\circ}F$  ( $52^{\circ}C$ ). Structural design calculations must be submitted to the code official when applying for a permit. The calculations must be signed, sealed and dated by a registered professional engineer when required by the statutes of the jurisdiction in which the project is being constructed.

#### 4.3 Installation:

The columns must not be installed where the maximum eccentricity (0.167 times the column width or diameter measured from the center line of the top of the column), maximum length and maximum allowable loads in accordance with Table 1 are exceeded.

Columns are attached either by use of a flashing cap at the top and two (2) aluminum brackets on opposite sides of the bottom; or two (2) aluminum brackets on opposite sides at the top and bottom of the column; or a column installation plate system.

The brackets, flashing cap and plates are attached to concrete or wood substrates using corrosion-resistant concrete anchors or wood screws as applicable.

#### 5.0 CONDITIONS OF USE

The Structural Fiberglass Fire Rated Columns and Structural Fiberglass Columns described in this report comply with, or are a suitable alternative to what is specified in, those codes listed in Section 1.0 of this report, subject to the following conditions:

5.1 Structural Fiberglass Fire Rated Columns (Interior Use):

- **5.1.1** The columns are used for load-bearing and nonload-bearing applications. Interior load-bearing columns are used to resist gravity axial loads.
- **5.1.2** The use of the columns to resist uplift or lateral loads resulting from seismic or wind applications is outside the scope of this evaluation report.
- **5.1.3** The columns must only be used on the interior of buildings.

5.1.4 The columns must only be used in the interior of buildings of Type III, IV and V construction, nonfire-resistance-rated or any construction under the IRC.

#### 5.2 Structural Fiberglass Columns (Exterior Use):

- 5.2.1 The columns are used for load-bearing and nonload-bearing applications. Exterior load-bearing columns are used to resist gravity axial loads.
- **5.2.2** The use of the columns to resist uplift or lateral loads resulting from seismic or wind applications is outside the scope of this evaluation report.
- **5.2.3** The columns must only be used on the exterior of buildings.
- **5.2.4** The columns must only be used on the exterior of buildings of Type V-B construction or any construction under the IRC.
- **5.3** The columns are manufactured at facilities in Troy, Alabama, under a quality control program with inspections by ICC-ES.

#### 6.0 EVIDENCE SUBMITTED

Data in accordance with the ICC-ES Acceptance Criteria for Fiber-reinforced Polymer (FRP) Composite Columns Used as Axial Load-Bearing and Nonload-Bearing Architectural and Decorative Columns (AC265), Approved October 2016.

### 7.0 IDENTIFICATION

#### Structural Fiberglass Fire Rated Columns:

Structural Fiberglass Fire Rated Columns must be labeled with the manufacturer's name (HB&G Building Products, Inc.) and/or the product trademarks as shown in Figure 1, HB&G PermaCast<sup>®</sup> Fire Rated, Dixie Pacific DuraCast<sup>™</sup> Fire Rated, Crown Column<sup>™</sup> Fire Rated, SpunCast Structural Fiberglass Column<sup>™</sup> Fire Rated, or Hartmann Sanders<sup>®</sup> Fire Rated, and the evaluation report number (ESR-1361). All Fire Rated Columns must also be labeled with the words "FIRE RETARDANT" and "Class B Interior Finish".

#### Structural Fiberglass Columns:

Structural Fiberglass Columns must be labeled with the manufacturer's name (HB&G Building Products, Inc.) and/or the product trademarks as shown in Figure 1, HB&G PermaCast<sup>®</sup>, Dixie Pacific DuraCast<sup>™</sup>, Crown Column<sup>™</sup>, SpunCast Structural Fiberglass Column<sup>™</sup> or Hartmann Sanders<sup>®</sup> and the evaluation report number (ESR-1361).

### TABLE 1—ALLOWABLE AXIAL LOADS (Ibs)<sup>1,2,3</sup> STRUCTURAL FIBERGLASS COLUMNS AND STRUCTURAL FIBERGLASS FIRE RATED COLUMNS

COLUMN TYPE AND NOMINAL SIZE (in)	WALL THICKNESS (in)		MAXIMUM LENGTH	MAXIMUM ALLOWABLE LOAD (lbs)⁴
	Bottom	Тор	(ft-in)	
6 - Square	0.377	0.341	8-0	8700
6 - Square	0.338	0.317	9-0	8925
6 - Square	0.299	0.292	10.0	6100
8 - Square	0.357	0.342	8-0	6725
8 - Square	0.347	0.353	10-0	4275
8 - Square	0.344	0.358	12-0	4500
10 - Square	0.508	0.512	8-0	5300
10 - Square	0.511	0.498	10-0	4325
10 - Square	0.549	0.505	12-0	7300
12 - Square	0.513	0.502	8-0	5875
12 - Square	0.507	0.490	10-0	5525
12 - Square	0.512	0.470	12-0	6325
8 - Round Tapered	0.335	0.310	8-0	3660
8 - Round Tapered	0.351	0.364	9-0	5300
8 - Round Tapered	0.298	0.365	10-0	4850
10 - Round Tapered	0.309	0.278	8-0	3650
10 - Round Tapered	0.294	0.427	10-0	4325
10 - Round Tapered	0.464	0.205	12-0	6100
12 - Round Tapered	0.352	0.363	8-0	5375
12 - Round Tapered	0.291	0.386	10-0	3890
12 - Round Tapered	0.410	0.422	12-0	5175

#### Table 1 Notes:

<sup>1</sup>SI Units conversion: 1 in. = 25.4 mm, 1 ft = 0.3 m, 1 lbf = 4.5 N. <sup>2</sup>Round columns include plain and fluted.

<sup>3</sup>Square columns include plain, fluted and recessed panels.

<sup>4</sup>Maximum Allowable Loads are based on a worst-case eccentricity of 0.167 times the column width or diameter measured from the center line of the top of the column.



ROWN







SPUNCAST STRUCTURAL FIBERGLASS COLUMN™ SPUNCAST STRUCTURAL FIBERGLASS COLUMN™ FIRE RATED

FIGURE 1—PRODUCT TRADEMARKS



# **ICC-ES Evaluation Report**

Most Widely Accepted and Trusted

# **ESR-1361 FBC Supplement**

Issued February 2017 This report is subject to renewal August 2017.

www.icc-es.org | (800) 423-6587 | (562) 699-0543

A Subsidiary of the International Code Council®

DIVISION: 06 00 00—WOOD, PLASTICS AND COMPOSITES Section: 06 50 00—Structural Plastics

**REPORT HOLDER:** 

HB&G BUILDING PRODUCTS, INC. 1015 BRUNDIDGE BOULEVARD POST OFFICE BOX 589 TROY, ALABAMA 36081 (334) 566-5000 800-264-4HBG www.hbgbuildingproducts.com marketing@hbgcompanies.com

### **EVALUATION SUBJECT:**

STRUCTURAL FIBERGLASS FIRE RATED COLUMNS (HB&G PermaCast<sup>®</sup> Fire Rated, Dixie Pacific DuraCast<sup>™</sup> Fire Rated, Crown Column<sup>™</sup> Fire Rated, SpunCast Structural Fiberglass Column<sup>™</sup> Fire Rated and Hartmann Sanders<sup>®</sup> Fire Rated)

STRUCTURAL FIBERGLASS COLUMNS (HB&G PermaCast<sup>®</sup>, Dixie Pacific DuraCast<sup>™</sup>, Crown Column<sup>™</sup>, SpunCast Structural Fiberglass Column<sup>™</sup> and Hartmann Sanders<sup>®</sup>)

# 1.0 REPORT PURPOSE AND SCOPE

### Purpose:

The purpose of this evaluation report supplement is to indicate that Structural Fiberglass Fire Rated Columns and Structural Fiberglass Columns, recognized in ICC-ES master evaluation report ESR-1361, has also been evaluated for compliance with the codes noted below.

#### Applicable code editions:

- 2014 Florida Building Code—Building
- 2014 Florida Building Code—Residential

#### 2.0 CONCLUSIONS

The Structural Fiberglass Fire Rated Columns and Structural Fiberglass Columns, described in Sections 2.0 through 7.0 of the master evaluation report ESR-1361, complies with the *Florida Building Code—Building* and *Florida Building Code—Residential*, provided the design and installation are in accordance with the 2012 *International Building Code*<sup>®</sup> (IBC) provisions noted in the master report under the following condition:

Design wind loads must be based on Section 1609, using the load combinations of Section 1605.3, of the *Florida Building Code—Building* or the design wind loads in Section R301.2.1 of the *Florida Building Code—Residential*, as applicable.

Use of the Structural Fiberglass Fire Rated Columns and Structural Fiberglass Columns for compliance with the High-Velocity Hurricane Zone provisions of the *Florida Building Code—Building* and *Florida Building Code—Residential* has not been evaluated, and is outside the scope of this supplemental report.

For products falling under Florida Rule 9N-3, verification that the report holder's quality assurance program is audited by a quality assurance entity approved by the Florida Building Commission for the type of inspections being conducted is the responsibility of an approved validation entity (or the code official when the report holder does not possess an approval by the Commission).

This supplement expires concurrently with the master report, issued August 2016 and revised February 2017.

ICC-ES Evaluation Reports are not to be construed as representing aesthetics or any other attributes not specifically addressed, nor are they to be construed as an endorsement of the subject of the report or a recommendation for its use. There is no warranty by ICC Evaluation Service, LLC, express or implied, as to any finding or other matter in this report, or as to any product covered by the report.

